



**DICA**<sup>®</sup>  
EST. 1988

# SAFE SETUP CHECKLIST

- 1** Know your responsibilities (OSHA 1926.1402).
- 2** Know the allowable ground bearing capacity (AGBC).
- 3** Identify any sub-surface hazards and avoid setting up on or near them.
- 4** Evaluate the ground and improve as needed to increase the allowable ground bearing capacity.
- 5** Know the maximum load the equipment can exert on each outrigger (Maximum outrigger reaction force).

To ensure a safe FIT every time, call DICA at:

**800.610.3422**  
**dicausa.com**



**DICA**<sup>®</sup>  
EST. 1988

# SAFE SETUP CHECKLIST

- 6** Select the right size outrigger pad or crane pad based on **outrigger loads**, **allowable ground bearing capacity** and **pad performance ratings**.
- 7** Avoid common sizing “rules of thumb” for selecting outrigger pads and crane pads.
- 8** Properly position blocking, cribbing or pads under outrigger floats.
- 9** Monitor every lift.
- 10** **Use common sense!** If it doesn't look right, stop. If it doesn't feel right, stop.

BM-035

To ensure a safe FIT every time, call DICA at:

**800.610.3422**  
**dicausa.com**