

TuffGrip Handle Replacement

For 1" and 1 1/2" Pad Thickness

Tools Required

- ▶ TuffGrip Replacement Kit
- ▶ 1/8" Nail Set
- ▶ Side Cutters (or Pliers)
- ▶ Hammer



1

Position the pad off the edge of a table or sturdy work surface so the pins will clear the table when coming out of the backside of the pad.



2

Use the hammer and nail set to drive the existing pins through the pad.



3

Drive the pins so they protrude out the bottom of the pad, at least 1/8" of an inch.



4

Turn the pad over. Using side cutters or pliers, grip the pin.



5

Using the cutters as a lever, pivot the pins out of the bottom of the pad.



6

Once both pins are removed, pull the old handle from the pad. Clear any debris from the holes in the edge of the pad.



7

Turn the pad over and insert the ends of the new handle into the holes. Make sure the ends are seated in the holes, with a minimum of 1" of handle into the hole.



8

Position the new pin in the existing hole. As you drive the pin through the pad and handle, make sure the pin is going perpendicular to the pad surface.



9

Use the hammer to set the pin flush with the top of the pad.



10

Use the nail to counter sink the pin just below the surface of the pad.



11

Pull the handle to ensure it is secure.

