



# TuffGrip Handle Replacement

For 2", 3" and 4" Pad Thicknesses

## Tools Required

- ▶ TuffGrip Handle Kit
- ▶ Screw Drive and Drill

1



2

Position the pad on a sturdy work surface. Using the provided T15 bit, back the screw out of the pad.



3

Once both screws are removed, pull the old handle from the pad. Clear any debris from the holes in the edge of the pad.



4

Insert the ends of the new handle into the holes. Make sure the ends are seated in the holes, with a minimum of 1" of handle into the hole.



5

Position the new screws in the existing holes.



6

Using a screwdriver or drill, drive the screws through the pad and handle ends.



7

Counter sink the head of the screws just below the surface of the pad.



8

Pull the handle to ensure it is secure.

